

Aspire Headboard instructions

Aspire

Step 1

Check the back of the divan for two holes, one toward either side. With cloth-covered frames, feel with your hand for the holes if the fabric's pattern makes them difficult to spot.

- Frames will already have bolts screwed into place, which makes finding the holes easier.
- Larger beds may have more than one screw hole in a vertical line in order to support larger, heavier headboards.

Step 2

If your frame already has bolts in place, remove them. Then line up the headboard's struts with the frame's screw holes. Insert a bolt through the gap in each strut and screw it into the screw hole. Begin tightening the bolt to the frame, but stop short of tightening it all the way to the point of immobilizing the headboard.

Step 3

Place your mattress on the frame so you can better judge how high you want your headboard to be. Raise or lower the headboard along its struts. If needed, loosen the bolts so you can do so more easily. Once you determine how high or low you wish it to be, use a level to confirm that both sides are raised equally high. Then tighten the bolts all the way to secure the headboard in place.