56985

CORONA BUDGET DINING CHAIR ASSEMBLY INSTRUCTIONS





IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

• Please ensure all fittings and parts are present before commencing with assembly.

• We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.

- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not place this product next to a radiator or in direct sunlight.


• Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.

• Make sure any spillage is wiped o ffimmediately.

• Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.

• For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.


• From time to time it may be necessary to tighten fittings, regular inspections should be carried out.




PARTS LIST (PER CHAIR)


Part Number	Part Code	Part Description	Quantity	<u>Carton</u>
1	S400-401-152-DC1-01C	Right Chair Side	1	1/1
2	S400-401-152-DC1-02C	Left Chair Side	1	1/1
3	S400-402-152-DC1-03C	Seat Pad	1	1/1
4	S400-402-152-DC1-04C	Back Rail	2	1/1
5	S400-402-152-DC1-05C	Seat Rail	2	1/1
6	S400-402-152-DC1-06C	Front Leg	2	1/1
7	S400-402-152-DC1-07C	Side Seat Rail	2	1/1
8	S400-402-152-DC1-08C	Stretcher	2	1/1


HARDWARE LIST














56985 **CORONA BUDGET DINING TABLE ASSEMBLY INSTRUCTIONS** DO NOT USE **IMPORTANT** PLEASE READ BEFORE YOU CONTINUE FURTHER FOR DOMESTIC USE ONLY **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

• Please ensure all fittings and parts are present before commencing with assembly.

• We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.

- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not place this product next to a radiator or in direct sunlight.


• Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.

• Make sure any spillage is wiped o ffimmediately.

• Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.

• For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.

• From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



Please Note:

The below parts have been number/colour coded to help identify them during assembly.

PARTS LIST

Part Number	Part Code	Part Description	Quantity	<u>Carton</u>
1	S400-401-152-DC1-01T	Table Top	1	1/1
2	S400-401-152-DC1-02T	Table Leg (Red Marking)	2	1/1
3	S400-401-152-DC1-03T	Table Leg	2	1/1
4	S400-401-152-DC1-04T	Short Frame Side	2	1/1
5	S400-401-152-DC1-05T	Long Frame Side	2	1/1



