




GARDEN MUST HAVES

"Essential items for your garden"

Assembly Instruction

Item No: 84905



Norfolk Leisure Lifestyle Ltd
Garage Lane
Setchey
Kings Lynn
Norfolk
PE33 0AX

www.norfolkleisure.com
service@norfolkleisure.co.uk

Tel : 01553 811 717

Parts list



(A) 4X




(B) 4X



(B1) 4X




(C) 3X




(C1) 1X




(C2) 4X



(D) 8X



(E) 1X




(F) 4X



(G) 4X



(G1) 4X




(O) 1X



(H) 1X




(H1) 1X



(I) 4X



(J) 1X




(K) 1X



(K1) 1X



(K2) 4X



(1) 52X
M6x15



(2) 12X
M6x25







(3) 16X
M6x30








(4) 16X
M6x45




(5) 16X
ST5x12



<1>



<2>





(G) 4X



(G1) 4X



(1) 16X M6x15



(4) 16X M6x45



(5) 16X ST5x12





(I) 1X





(0) 1X



4

<3>












M6x30



<4>


(E) 1X

(C) 3X

(C1) 1X

M6x25
(2) 4X

S4
(I) 1X

(J) 1X
6

<5>





M6x25

② 4X




S4

① 1X



④ 1X

<6>



② 4X



M6x25

② 4X



M6x15


① 4X



S4

① 1X

<7>





(H) 1X




(H1) 1X



(K) 1X


<8>






(K1) 1X

<9>



(K2) 4X

<10>



Warning

1. It is the consumer's responsibility to comply with any relevant local planning requirements.
2. Three persons are required for assembly. The tools required are the screwdriver and spanner supplied, a stepladder and other relevant safety items such as gloves.
3. This gazebo will take at least 1-2 hours to set up. You must allow enough time to complete the assembly. Do not leave it unattended if not fully assembled, even if bolted to the ground.
 - a. Make sure that all components are in the box. Read instructions carefully before starting the assembly.
 - b. Follow all instructions carefully to assure the strength of the gazebo.
 - c. In order to avoid damage to the gazebo and its components, use appropriate tools. Do not use the structure as a support; a stepladder is recommended.
 - d. Check all bolts and screws on a regular basis to maintain the solidity of the structure.
 - e. Keep the instructions and parts list for further use.

Maintenance

- In the event that your gazebo needs replacement parts, repairs or you require assistance with regards to assembly; please contact the original place of purchase
- For cleaning: Use a mild domestic soap or soft detergent and wash with warm water using a sponge or microfibre fabric. Rinse with clean water.
- The canopy and curtains must be removed for winter storage.

Excluded

- Damages due to vandalism, abuse and incorrect use of the product are not covered by the warranty.
- Damages due to extreme weather conditions such as thunderstorm, hail and high winds are not covered by warranty.