




ASSEMBLY INSTRUCTION


PC 611

HELP LINE NUMBER 01443 816982

A		M4	1PC
B		1/4"*25mm	10PCS
C		1/4"*28mm	8PCS
D		Ø25*360mm	4PCS
E		Ø12*60mm	8PCS
F		Back Panel	1PC
G		1/4"*Ø16*1.5T	8PCS
H		Legs	2PCS
I		Top Panel	1PC
J		Middle Panel	1PC
K		Base Panel	1PC
L		Side Panel	2PCS
M		1/4"*Ø30*2mm	4PCS
N		#8*38mmL	1PCS
O		Safety strap	1PCS
P		Wooden screw- #4*12mmL	1PCS



STEP1



ASSEMBLY INSTRUCTION

PC 611

HELP LINE NUMBER 01443 816982

STEP2

WARNING! Furniture can tip over unexpectedly and cause injury. This item **MUST** be fixed to a wall using the anti-tip kit provided. Be sure to use the correct wall fixings suitable for the walls in your home. Seek professional advice if you are unsure.

