














# ASSEMBLY INSTRUCTION


## PC 201

HELP LINE NUMBER 01443 816982


A		M4	1PC
B		1/4"*80mmL	8PCS
C		1/4"*15mmL	4PCS
D		Ø20*5mm	4PCS
E		Brown end caps	8PCS
F		Left leg	1PC
G		Right leg	1PC
H		Middle metal frame	1PC
I		Wood cross bar	1PC
J		Top glass	1PC
K		Back panel	1PC
L		#4*15mmL	11PCS




### STEP1



### STEP2



### STEP3



### STEP4

