


# Beatrice Storage Bench


Assembly & Care Instructions



**Dunelm**  
[www.dunelm.com](http://www.dunelm.com)

1. Check you have received all parts listed on the component and hardware pages and the correct quantity of each. Beware that sometimes parts are packaged within the product so not immediately visible after opening. Please check the assembly section for more details. If anything is missing, stop assembling the product and contact our customer service team.
2. Check all parts are intact and undamaged. Any issues, stop assembling the product and contact our customer service team.
3. Check you have the right tools for the job. Required tools which are not provided are listed below. If you are unsure of how to use these tools, please contact a professional tradesperson. We recommend Airtasker as an easy way to find trades people in your local area.

## Tools required which are not included

|   |   |  |
|---|---|--|
| Flat head screwdriver   | Cross head screwdriver  |  |
|  |  |  |











## Safety advice.

### Dear Customer

- **IMPORTANT** – The first step you need to take is to ensure your safety! Please take the time to read and understand these instructions before assembling the product.
- Please keep these instructions for future reference.
- This item is intended for indoor use only – unless otherwise specified. Avoid exposure to humid conditions.
- Assembly to be carried out by a competent adult only.
- During assembly children should be kept away from the product due to possible risk of injury. The product may contain small parts that could also cause choking if swallowed.
- Products can be dangerous if incorrectly installed or assembled. Assembly should be carried out by a competent person and instructions followed. No liability will be accepted for damage or injury caused by incorrectly installed or assembled products.
- Never use an electric drill to assemble a product, as this can cause damage to parts.
- Regularly check all fastenings to ensure that they are properly tightened.
- Restraine children from climbing or playing on or around the product. Always consider where products are positioned to ensure children cannot get access to long cords or windows.
- Some products will be supplied with anti – tip kits which should always be used to secure the product to the wall and prevent tipping.
- Keep all plastic wrapping materials away from babies and children to avoid danger of suffocation.
- Ensure that all packaging is disposed of carefully and responsibly. Please recycle where possible.
- Once items are part or fully assembled, they are not returnable unless faulty.


| Max weight limit  | No. of people to assemble   | Assembly difficulty  | Time to assemble  |
|---|---|--|---|
|  |  |  |  |
| 150 KG  | 2 recommended   | Moderate   | < 1 hour  |

## Parts supplied.

| Ref       | Part  | Visual  | Qty      |
|-----------|---|---|----------|
| <b>1</b>  | Top panel<br>(115 x 37.5 x 2.5 cm)                |     | <b>1</b> |
| <b>2</b>  | Left wall<br>(36.5 x 5 x 1.5 cm)                  |    | <b>1</b> |
| <b>3</b>  | Right wall<br>(36.5 x 5 x 1.5 cm)                 |    | <b>1</b> |
| <b>4</b>  | Back wall<br>(109.5 x 5 x 1.5 cm)                 |     | <b>1</b> |
| <b>5</b>  | Left side panel<br>(42.5 x 35.5 x 3.6 cm)         |     | <b>1</b> |
| <b>6</b>  | Right side panel<br>(42.5 x 35.5 x 3.6 cm)        |     | <b>1</b> |
| <b>7</b>  | Front crossing panel<br>(103.8 x 3.6 x 2.5 cm)    |    | <b>1</b> |
| <b>8</b>  | Left partitional panel<br>(31.7 x 29.5 x 1.5 cm)  |   | <b>1</b> |
| <b>9</b>  | Right partitional panel<br>(31.7 x 29.5 x 1.5 cm) |   | <b>1</b> |
| <b>10</b> | Back panel<br>(103.8 x 29.5 x 1.5 cm)             |  | <b>1</b> |
| <b>11</b> | Apron<br>(103.8 x 8 x 1.5 cm)                     |   | <b>1</b> |
| <b>12</b> | Base panel<br>(103.8 x 33.9 x 1.5 cm)             |   | <b>1</b> |
| <b>13</b> | Leg<br>(10 x 3.5 x 2.4 cm)                        |  | <b>2</b> |
| <b>14</b> | Shelf<br>(33.8 x 31.5 x 1.5 cm)                   |   | <b>2</b> |
| <b>15</b> | Shelf<br>(32.8 x 31.5 x 1.5 cm)                   |   | <b>1</b> |
| <b>16</b> | Door panel<br>(34.2 x 26.5 x 1.8 cm)              |   | <b>3</b> |
| <b>17</b> | Cushion<br>(109 x 35 x 9.3 cm)                    |   | <b>1</b> |


## Hardware supplied.

| Ref      | Hardware & dimension (mm) | Qty       |
|----------|---------------------------|-----------|
| <b>A</b> | Wooden Dowel M8×30mm      | <b>36</b> |
| <b>B</b> | Screw M5×40mm             | <b>18</b> |
| <b>C</b> | Screw M3.5×14mm           | <b>36</b> |
| <b>D</b> | Bolt M4×22mm              | <b>3</b>  |








| Ref      | Dimensions | Visual | Qty       |
|----------|------------|--------|-----------|
| <b>E</b> | 7×43mm     | 407523 | <b>26</b> |
| <b>F</b> | N/A        | 405451 | <b>26</b> |
| <b>G</b> | N/A        | 408670 | <b>4</b>  |
| <b>H</b> | N/A        | 405350 | <b>2</b>  |
| <b>I</b> | N/A        | 406342 | <b>4</b>  |
| <b>J</b> | N/A        | 406156 | <b>2</b>  |

| Ref      | Dimensions | Visual | Qty       |
|----------|------------|--------|-----------|
| <b>K</b> | N/A        | 403122 | <b>3</b>  |
| <b>L</b> | N/A        | 408778 | <b>12</b> |




## Assembly instructions.

|   |   |
|---|---|
|    | <p><b>ALWAYS</b> lay each panel down on a clean and level area, ideally in the room of intended use, ensuring there is enough room to maneuver around the item.</p> |
|     | <p><b>NEVER</b> pull furniture into place as this causes damage to the internal structure and feet fixings. Always lift to move.</p>                                |
|   | <p><b>NEVER</b> flip your upholstery allowing corners to hit the floor as structural damage can be caused. Always turn gently.</p>                                  |




## Assembly instructions.



**2**




**3**



F x 3




**4**




B x 4



**5**






**6**








## Assembly instructions.

7




8






11



F x 2




12



B x 8






**13**





**Ex 11**



**14**




**15**



**16**



**17**



**x 2**



C x 8

D x 2


I x 4

K x 2







**18**



C x 8




**19**



**C x 8**



**20**



C x 4



D x 1




J x 2




K x 1









**21**



C x 4




**22**




**C x 4**



**23**



**22**



## General Care

- **DO** from time-to-time check that there are no loose screws or bolts, and the frame is stable. Stop using the product if still unstable after all screws and bolts are tightened.
- **DO** minimise surface fabrics from fuzzing or pilling with use by following our cushion care advice. De-bobble if necessary.
- **DO** keep out of direct sunlight as discolouration, fading and fabric deterioration can occur.
- **DO** avoid using in sunny conservatories or rooms with direct sunlight as discolouration, fading and fabric deterioration can occur.
- **DO** position 30cm away from heat sources, such as radiators, to prevent fading or marks.
- **DO** restrain children and pets from climbing, jumping or clawing at upholstery.
- **DO** consider the colour choice of your soft furnishings (dark-coloured scatters on light coloured upholstery) to avoid colour transfer. Be aware that dye transfer from clothing, such as denim, can be permanent.
- **DO** ensure that the plastic or felt protectors are securely fitted and in place when furniture is on a wooden or laminate floor.
- **DO NOT** use in excessively cold, hot or humid rooms as structural and fabric damage can occur.
- **DO NOT** place hot items such as cups, laptops or hot water bottles directly onto upholstery as permanent marks may occur.
- **DO NOT** allow household chemicals such as baby wipes, fake tan, cleaning solutions and skin lotions contacting the surface fabric as these can cause damage and stains.
- **DO NOT** allow sharp items such as toys, buckles or jewellery contacting the surface fabric as these can snag, pull or tear them.
- **NEVER** pull or cut fabric threads that have been snagged. Always thread them back into the fabric.
- **NEVER** drag furniture as this can weaken the frame and feet fixings. Always lift to move.
- **NEVER** sit on furniture arms as irreversible structural damage can be caused.
- **NEVER** rock backwards on two legs of chairs, as this will weaken the joints.

## General Cleaning


- **DO** vacuum and brush weekly with a soft brush, as dust and dirt build up will accelerate wear and dull colours.
- **DO** address spills and stains immediately to avoid them settling into the fabric fibres. Blot or soak up spills with a dry soft colourfast cloth.
- **DO** use specialist upholstery cleaners and always follow the manufacturer's instructions. Spot test on a hidden area before using. We recommend using a professional cleaning service for cleaning your furniture in situ for the best results.
- **DO NOT** soak or allow the fabric to become wet.
- **NEVER** rub, scrub or use washing up liquid, detergents or bleach on stains as this could damage the fabric and cause discolouration.
- **NEVER** wash or dry clean covers, including cushion covers provided with upholstery items, as this can affect the fire-resistant and other added coatings the fabric has been treated with. It can also impact the long-term performance of the fabric and result in colour change or premature fading.

A good cushion care routine is important to ensure your upholstery retains its shape and evenly wears. Cushions naturally soften over time, however there are a few things you can do to help.

- When new upholstery arrives, you may notice that some of the cushions are creased or have been compressed during transit. This can be simply corrected by following the below steps to re-distribute the filling and reshape.
- Regularly plump back, seat, scatter and bolster cushions by pounding, teasing and shaking to add air back into the fibres to help restore their shape.
- Regularly smooth any ripples or creases in the cushion cover, by running your hands over the fabric and ensure all seams are aligned and in the correct position.
- Remove removable cushions to plump for the best results. If cushions are not removable, plump the fibres in situ.
- If the cushions are removable, regularly switch cushion positions to even out wear.
- If the cushions are reversible, turned daily to further even out wear.
- Using your hands is the best way to care for your cushions. Using sharp tools or objects may damage the fabric.
- Large cushions typically lose their shape faster than smaller cushions. This is a natural characteristic as the fibres have more space to move. This is not a design, quality or care issue.

### Foam Filled Cushions

Cushions made from foam do not require the same level of daily plumping as fibre filled cushions, however they do require regular neatening, turning and switching of cushion positions to prolong their life and even out wear.



## General furniture care.

---

- Uneven floors could give the impression that doors are out of alignment or that the furniture is wobbly. Be aware of this and compensate, if necessary, by adjusting the hinges or packing a corner to level the item. Please refer to the assembly instructions and adjust accordingly.
- If your furniture becomes stained, scratched, chipped or suffers other damage, we recommend professional help is sought to restore it. Please contact our customer services line for recommended agents.
- **DO** move items such as ornaments or coasters around periodically to allow the colour to mellow evenly.
- **DO** use mats and coasters to protect the surface from heat, liquids, or items that may cause scratches.
- **DO** ensure plastic or felt feet protectors are securely fitted into place on the feet and legs to avoid scratches.
- **DO** check fittings and fixings from time-to-time and tighten when necessary. Stop using the product if still unstable after all screws and bolts are tightened.
- **DO NOT** drag your furniture when moving it as this can damage joints. Always lift furniture into place.

## Specific material care.

---

### Foil Care

- **DO** avoid water or other liquids contacting scratches or chips as this can cause the surface to bubble and lift.
- **DO** only clean using a damp cloth and mild detergent. Aim to dust weekly with a soft, lint-free cloth or duster to prevent any build up of dirt.
- **DO** remove any spills immediately to avoid staining.
- **DO NOT** place directly in front of heat sources such as radiators or fires as timber can be affected by temperature and humidity which may cause cracking and warping.
- **DO NOT** in direct sunlight, as this will cause the colour to change quickly.
- **DO NOT** use bleach or abrasive cleaners.
- **DO NOT** use too much water when cleaning, the cloth should just be slightly damp.
- **DO NOT** use abrasive polish or silicon-based polishes as these can affect the finish over time.

---

If you have any issues with this product, you can call our Customer Service team on:  
0345 165 6565 Monday to Friday 9am to 5:00pm.

Alternatively, you can contact our team by Live Chat on: [Dunelm.com](http://Dunelm.com)  
Monday to Friday 8am – 8:30pm  
Saturdays 8am – 5:30pm  
Sundays and bank holidays 9am – 4:30pm.



**Dunelm (Soft Furnishings) Ltd. LE7 1AD  
& Dunelm (Soft Furnishings) Holdings  
Ltd. Dublin D12 WR25**