




GARDEN BENCH

ITEM CODE:4508 CONTENTS:



NOTES TO CUSTOMERS.

Please check that your parcel contains all the parts listed above.


- Please keep all the packaging for the product until you are satisfied with your purchase as we cannot accept any returned item not in the original packaging.
- For the protection of your furniture we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- Please ensure that you read the instructions before assembling the product.
- Please do not force or over tighten the nuts. If a nut becomes stuck, unscrew it and start again.
- Ensure you have plenty of space to assemble the item in, it is also recommended that you assemble the item close to where it will be kept.

ASSEMBLY INSTRUCTIONS

(Assembly will be easier with 2 people – only connect parts loosely until assembly is complete, then tighten once the bench is standing squarely)

STEP 1:

Loosely connect the left and right leg sections to the back section using 4 x longer bolts, washers marked E on the Contents.



STEP 2:

Loosely connect the seat section to the assembled leg sections using 4 x shorter nuts bolts & washers marked D on the contents.

Tighten all nuts & bolts and fit nut covers



CARE AND MAINTENANCE

- This set has been tested for a maximum load of 110 kg static weight only.
- Under no circumstances should you abruptly sit or jump on the Bench.
- Do not stand or kneel on the Bench.
- Please check all the assembly work before you sit on the bench.
- Make sure all the screws and bolts are tightened properly.
- Periodically check all fixings to ensure they remain secure.
- Prolonged exposure to the elements will inevitably lead to weathering, although this may be considered a feature, original or alternative colours can be achieved by appropriate application of any outdoor paint suitable for metal.
- Store away indoors throughout winter to preserve appearance.
- Clean using a mild detergent – do not use abrasive cleaners
- When sitting in the Bench do not lean back and put excessive pressure on the back rest.
- Keep all four bench legs on the floor when using the bench.

Should you require further details or assistance, please contact our
Customer care line on 01562 753040

GABLEMERE LTD DY11 7FB