



Item code: 4511 - 4512

Lutyens Style Garden Bench

To keep your furniture at its best, we recommend the following care:

Please ensure that you check all the contents of your delivery packaging against the contents list on the enclosed Instruction Manual before assembling the item.

Keep all the packaging including internal fittings until you have successfully put together and installed your purchase.

We will only accept a return of this product if it is repacked in the original packaging.

Use a clean damp sponge to clean the whole product and dry it with a clean cloth.

Dust once a week using a soft cloth.

Wipe up spills immediately.

The product should be put on a flat surface.

Periodically re-fasten all screws.

Caution:









Avoid placing hot or wet items directly on the surface as they can leave marks which are difficult to remove.

Do not apply any abrasive chemicals that may spoil the product.


Do not use a pressure washer or you will damage the texture of the wood.

Please note:


Wood is a natural product. This means it is subject to variations in colour and grain. Fine cracks may appear after long periods of hot, dry weather. These do not impair the product's quality and function.

A1 x1 	A2 x1 	B x1 	D x1 
1  Screw M7 x 90mm = 4pcs	2  Screw M7 x 40mm = 2pcs	3  Screw M6 x 35mm = 4pcs	4  Allen key = 1pc


Step 1:



Step 2:



Step 3:



Step 4:

