


Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102

Assembly Instructions



Product size:
DIA120*H74 CM
W180*D120*H74 CM (EXTENDED SIZE)



**Furniture should be covered/stored whilst not in use
to prolong its longevity.**

(It should also be covered in adverse weather.)

This product is for domestic use only.

**IMPORTANT, PLEASE RETAIN FOR FUTURE REFERENCE
READ CAREFULLY.**

Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102

Before you start



Warnings

IMPORTANT, RETAIN FOR FUTURE REFERENCE READ CAREFULLY

See enclosed instructions for assembly, safety and care information.

Failure to follow the warnings could result in serious injury.

Handle heavy parts with care.

Ensure that this product is fully assembled as illustrated before use.

This product should only be used on firm, level ground.

The product contains small parts which could pose a risk to young children. Keep small parts out of reach of children.

Do not stand or climb onto this product.

This product is intended for **domestic use** only.

Ensure the product is always placed on level ground.

Furniture can be dangerous if incorrectly used. No liability will be accepted for damage or injury caused by incorrect use of this product.

Take care when opening and folding furniture. Keep your hands away from moving parts in order to prevent trapping your fingers. Children should not open or close the furniture.

This table is not intended to support a parasol separately. A parasol base with suitable weight must be used to support your parasol.



Dos

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on suitable surface to prevent scratching your product.

Check the pack and make sure you have all of the parts listed. In the event of problems or missing parts, please contact the seller.

Check all screws and bolts are tightened and inspect regularly.

During severe weather conditions, including high winds, rain, hail, thunderstorms, extreme heat and cold temperatures, the product should be stored inside in a cool, dry place.

To best preserve this product, please use a protective cover when your furniture is not in use. We would also recommend using a gazebo or parasol over your furniture during the summer period and prolonged sunny spells. This will help prevent harmful UV rays from damaging and discolouring the material.

Timber is a natural product and contains coloured resins which may initially bleed out of the timber when its gets wet. Therefore we recommend that care is taken to protect patios and decking from possible staining where the product comes into contact with the ground. The furniture will stabilise in its environment after the first few times it gets wet.

Wood is a natural material whose appearance will deteriorate when left outside. A surface coating is vital in protecting it from premature darkening, or splitting, when exposed to the weather. The finish should be regularly maintained to ensure that the wood is protected from moisture and the furniture continues to look at its best.

This product has been treated with furniture oil during manufacture and the wood requires further treatment before being left outside. When applying furniture oil particular care should be given to the end grain and any joints or crevices, please note that is the products needs to be put together the first

coat should be applied to all wood surfaces before assembly.

Should you choose not to treat your furniture, then it will turn a greyish colour and develop cracks. Light sanding can restore the original colour after which furniture oil can be regularly applied in accordance with the instructions above.

A liberal coating of furniture oil should be given to the furniture before it is laid up, and again when it is removed from storage.

Clean your product with a sponge and warm soapy water then wipe with a clean, dry cloth.

Ensure that the product is clean and dry before storage.

Where instructions as to the; storage, commissioning, installation, use and maintenance of the goods or (if there is none) good trade practice are not followed and a defect arises this will void the 12 month manufacturer's guarantee on the product.



Don'ts

Do not use scourers, abrasives, washing powders, chemical cleaners or any other substances containing abrasives since these substances can damage the product.

To preserve the product do not place greasy / oily items directly onto the wooden surface.

Do not place very hot or very cold items on the wooden surface unless adequately thick place-mats are used to prevent such items from coming into contact with the wood.

Do not strike the product with hard or pointed items.

Do not sit or lean on the arms of this product.

Do not use power tools to construct this product.

Do not tighten screws until fully assembled.

Do not overtighten screws or bolts.

Do not use this product if parts are missing, damaged or worn.

Do not stand or climb onto the product and do not use it as a ladder, as this could lead to it unbalancing and overturning.

Never tilt the product during use.

Never drag furniture when moving it, always lift it.

Number of people required for assembly

Two people



Time to assemble



30 minutes





Tools required




Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102

Components, fixtures & fittings (not actual size)

Parts List					
Part No.	Diagram	Qty.	Part No.	Diagram	Qty.
A	 Table Leg	2 PCS	B	 Connecting Bar	2 PCS
C	 Table Top	1 PC	1	 Self-Taping Screw M6*70mm	4 PCS
2	 Bolt M6*35mm	6 PCS	3	 Allen Key	2 PC




Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102

Step by step assembly instructions

Step One


With the help of another person, open the cartons, place the Table Top (C) upside down on a flat, non-abrasive and soft platform to avoid scratching the table surface or rim.



Step Two

With the help of another person, attach the Connecting Bars (B) to the Table Legs (A) using Self-Taping Screws (1).

Tighten with Allen Key (3).




Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102

Step Three

With the help of another person, attach the above partly-assembled part to the Table Top (C) using Bolts (2).

Tighten with Allen Key (3).




Step Four

With the help of another person, stand the table.

Your table now is ready for use.

Please note the table is in its unextended version.





Turnbury Round Extension Table 120-180 cm

ITEM CODE: FSC110102


Step Five

To use its extended version, release the Safety Lock under the table top. Lift the middle folding part and let the table top parts align each other.



Step Six

Fasten the Safety Lock like below.
Your Extension Table is ready for use now.



The table is closed by reverse steps.

Children are NOT allowed to extend/fold this product without adult guidance.
This table is not intended to support a parasol separately.
A Parasol Base with suitable weight must be used to support your parasol.


PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

HENLEY GREY TEXTYLENE RECLINING FOLDING HIGH BACK ARMCHAIR

Instruction Manual

Product size:

H1120 x W740 x D590mm



ACACIA

HENLEY GREY TEXTYLENE RECLINING FOLDING HIGH BACK ARMCHAIR

Instruction Manual

IMPORTANT! RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

Warnings

See enclosed instructions for assembly, safety and care information.

Failure to follow the warnings could result in serious injury. Ensure that this product is fully assembled as illustrated before used.

This product should only be used on firm, level ground. Keep hands away from folding mechanisms to prevent possible entrapment or injury.

This item is intended for max use 120 kgs, do not exceed this weight.

Do's

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packing materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.

Check all screws or bolts are tightened and inspect regularly.

Make sure the legs remain in contact with the ground.

We recommend the use of furniture covers to protect your product when not in use.

During bad weather and winter months the product should be stored in a cool dry place. Before storage ensure that it is clean and dry.

Timber is a natural product and contains coloured resins which may initially bleed out of the timber when its gets wet. Therefore we recommend that care is taken to protect patios and decking from possible staining where the product comes into contact with the ground. The furniture will stabilise in its environment after the first few times it gets wet.

Wood is a natural material whose appearance will deteriorate when left outside. A surface coating is vital in protecting it from premature darkening, or splitting, when exposed to the weather. The finish should be regularly maintained to ensure that the wood is protected from moisture and the furniture continues to look at its best.

This product has been treated with furniture oil during manufacture and the wood requires further treatment before being left out side. When applying furniture oil particular care should be given to the end grain and any joints or crevices, please note that is the products needs to be put together the first coat should be applied to all wood surfaces before assembly.

To prolong the life of this wooden furniture, it should be protected from severe weather and stored under cover during winter. A liberal coating of furniture oil should be given to the furniture before it is laid up, and again when it is removed from storage.

Should you choose not to treat your furniture, then it will turn a greyish colour and develop cracks. Light sanding can restore the original colour after which furniture oil can be regularly applied in accordance with the instructions above.

To clean wipe with a sponge and warm soapy water then wipe with a dry, clean cloth

Don'ts

Do not use power tools to construct this product.

Do not tighten screws until fully assembled.

Do not overtighten screws or bolts.

Do not use this product if parts are missing, damaged or worn.

Do not stand on the product.

Do not sit on the arms of the product.

Never use a pressure hose or washer to clean the product

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

One person to fold/unfold and lift the chair into position


Time to assemble



5 minutes

HENLEY GREY TEXTYLENE RECLINING FOLDING HIGH BACK ARMCHAIR
Instruction Manual


Getting to know your product




HENLEY GREY TEXTYLENE RECLINING FOLDING HIGH BACK ARMCHAIR

Assembly Instructions


1
Open
the
chair



2
Fold
the
chair



3
To recline the chair: keep the arms of the chair lifted when moving forward (1) then move back and stop in the required position (2)



Keep fingers away from folding mechanism.

