ASSEMBLY INSTRUCTIONS DESSER LOFT CHAIR

INCLUDED IN THE BOX:

- 1 x Screwdriver
- 4 x Seat Frame Screws

ASSEMBLY STEPS:

1. Unpack and Identify Parts

Carefully unpack the chair and place all components on a soft surface to avoid damage.

You should have two main parts:

Bottom Half (with legs pre-attached)

Top Half (backrest and arms combined)

2. Align Chair Halves

Position the top half of the chair onto the bottom half, aligning the predrilled holes on both sections.

3. Secure with Screws

Using the 4 included screws and the screwdriver provided, fix the top half securely to the bottom half.

Tighten each screw firmly, but avoid over-tightening.

4. Final Check

Gently press and rock the chair to ensure everything is secure and stable.

NEED HELP?

Give us a call on 0161 834 1795 or email info@desser.co.uk.

