
HAMILTON

Aluminium
Curtain Pole Brackets

Installation & Care Instructions

Suitable for Pencil Pleat & Pinch Pleat Curtains



Dunelm
www.dunelm.com

Getting Started

Hamilton Aluminium Curtain Pole Brackets

A. Check you have received all parts supplied listed and the correct quantity of each. Beware that sometimes parts are packaged within the product so not immediately visible after opening.

B. Please check the installation guide section for more details. If anything is missing, stop installing the product and contact our customer service team.

C. Check all parts are intact and undamaged. Any issues, contact our customer service team.

D. Check you have the right tools for the job. Required tools which are not provided are listed overleaf. If you are unsure of how to use these tools, please contact a professional tradesperson. We recommend Airtasker as an easy way to find trades people in your local area.

E. Ensure that all wall plugs and screws provided are suitable for your type of wall/window.

F. We recommend two people to fit longer length tracks 240cm and above.

Care Advice

Wipe clean only.

Note:
Modification of the design or configuration of the track or its integral or non-integral component parts shall not be made without consulting the manufacturer.

7902L-INS-01

Safety Advice

Dunelm






Important
Safety Instructions

Dear customer


- **IMPORTANT –** The first step you need to take is to ensure your safety! Please take the time to read and understand these instructions before installing the curtain track.
- Please keep these instructions for future reference.
- This item is intended for indoor use only – unless otherwise specified.
- During installation children should be kept away from the product due to possible risk of injury. The product may contain small parts that could also cause choking if swallowed.
- Products can be dangerous if incorrectly fitted or assembled. Installation should be carried out by a competent person and instructions followed. No liability will be accepted for damage or injury caused by incorrectly installed or assembled products.
- Restrain children from climbing or playing on or around the product. Always consider where products are positioned to ensure children cannot get access to long cords or windows.
- Keep all plastic wrapping materials away from babies and children to avoid danger of suffocation.
- Ensure that all packaging is disposed of carefully and responsibly. Please recycle where possible.
- Once items are part or fully installed, they are not returnable unless faulty.


Tools

Tools required which are not included

Drill	Flat head screwdriver	Cross head screwdriver	Spirit level	Tape measure	Pencil
					

Parts Supplied

Ref	Part	Visual
1	Bracket*	


Ref	Hardware & Dimension (mm)	Visual	Qty
Bracket*	32mm screws		2 per bracket

*Bracket design will vary depending on which bracket pack you have purchased: Single or double bracket.


Exploded Diagram

Dunelm

Single bracket



Double bracket



Wall Fixing Guide

Important




When drilling into walls always check there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your blind. If you are unsure of the below guidance, consult a qualified tradesperson for advice or help.




Hints

1. General Rule; Always use a larger screw and wall plug if you are not sure.
2. Ensure you use the recommended drill bit to match the wall plug and hole size.
3. Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4. Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure the plug is fitted below the ceramic tile to avoid splitting or cracking.
5. Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Wall Plug Types

General purpose fittings provided,but you can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plastic board.

GENERAL PURPOSE	PLASTERBOARD	HAMMER
		
For light loads only. Options available for most wall types.	For light loads only. Attach into plasterboard.	For light loads only. For solid walls covered with plasterboard. Allows the fixing to be attached into brick behind.

CAVITY - LIGHT LOAD	CAVITY - HEAVY LOAD	SHIELD ANCHOR
		
Light load cavity wall plug for use into plasterboard or hollow wooden doors.	Heavy load cavity wall plug for use into plasterboard or hollow wooden doors.	For heavier loads into masonry, brickwork or concrete.

Care and maintenance


Regularly check the fixings to ensure the wall plug or screws have not become loose. Tighten or stop using the product if they have.

Installation Guide

Dunelm

1. Measuring your window

First check the width of your window recess, the width of the track should be a minimum of 20cm wider than the windows recess (minimum 10cm each side).




Using a spirit level and pencil, mark a straight line along the wall to the required track length.

Installation Guide

2. Preparing the brackets

Detach the aluminum back plate from the bracket arm.




The end bracket back plates should be positioned a minimum distance of 10cm above the window recess and positioned approximately 10cm from the end of the track. (See Step 1)

For 200cm track:

A middle back plate should be positioned centered between the end brackets.

For 360/400cm tracks:

A further 2 brackets are supplied which should be equally spaced between the end and middle bracket.



Once all back plates are fitted, the cover plates can slide over to be held in place when the bracket arms are fixed in step 4.

3. Shortening the track

Please ensure you have the correct size of track before cutting down to size


For tracks up to 180cm: Cut from one end only.

For tracks over 240cm: Cut equal amounts from the end of both track pieces.
Eg. To reduce the overall length by 10cm you need to remove 5cm from one end of each piece.

A. Remove end stop before cutting the track by undoing the screw.

B. Using a hacksaw, carefully cut to length ensuring a straight edge remains. Remove all burrs using a file.

C. Once you have desired length, reattach the end stop by inserting it back into the track and tightening the screw.




4. Assembling the track

Tracks 240cm and wider are supplied in 2 pieces with a track joiner.


This joiner plate slides into the top channel of the track and is secured by tightening 4 grub screws, 2 each track side.

Attach middle bracket arm screw to the empty middle hole in the joiner as shown.




5. Preparing the track


The bracket arms are first fitted loosely to the track; the star washer locates into the top channel of the track.




The bracket then slides along the track to align approximately with wall back plates. Where applicable repeat this for the second track on the double layer track kits. For 360/400cm note the middle bracket fits to joiner plate as described on page 10.



Load gliders into the bottom channel and fit an end stop eye 2cm from each track end by inserting and twisting by 90˚.



The end caps should then be fitted to each end of the track by tightening the grub screw.




3. Fitting the track to the wall

Note: When installing longer lengths, assistance may be required to support the rail at the other end. We recommend two people to fit longer length tracks.

Offer the track up to the back plates on your wall, adjusting the position of the loose bracket arms to match up if necessary.


Slot each into position and tighten the back grub screw on the top of each bracket arm - please take care not to over tighten.


Check the track is centered on the brackets before tightening each top track screw as shown - taking care not to over tighten.



4. Attaching the curtains

Count out the number of gliders in track (including end stop eyes) and attach a matching number of curtain hooks equally spaced to your curtain. Using the eyelets on the gliders, attach your curtain hooks.





Note: Additional gliders can be purchased separately and added to the track if required. Simply remove the end stop, slide the gliders into the bottom channel of the track and replace the end stop securely.

Customer Service Centre

If you have any issues with this product, you can call our **Customer Service** team on: **0345 165 6565** Monday to Friday **9am to 5:00pm.**

Alternatively, you can contact our team by Live Chat on:
Dunelm.com
Monday to Friday 8am - 8:30pm
Saturdays 8am - 5:30pm
Sundays and bank holidays 9am - 4:30pm

Recycle
FSC www.fsc.org
MIX
Paper | Supporting responsible forestry
FSC® C204602

www.dunelm.com
Dunelm (Soft Furnishings) Ltd. LE7 1AD &
Dunelm (Soft Furnishings) Holdings Ltd. Dublin D12 WR25
Manufactured in China