


Please read all the instructions carefully and retain for future reference.



To assemble the handle, remove the poles and mop head from the bucket.

STEP 1: Unscrew the locking cap (D) from the mop head (E) by twisting it in an anticlockwise direction.

STEP 2: Place the locking cap (D)

over the small end of pole (C), towards the locking lever end.

STEP 3: Insert the small end of pole (C) into the mop head (E) and tighten the locking cap (D) in a clockwise direction until the pole is secure.

STEP 4: Take pole (A) and insert into pole (B), twisting in a clockwise direction until secure.

STEP 5: Insert the microfibre head into the plastic mop head.

STEP 6: Place the mop vertically downwards and switch the pole lock button to "ON" position for wash and dry.


STEP 7: After wash and dry, switch the pole lock button to "OFF" position for mopping floor. (The length of the handle is adjustable to suit your needs. (Switch to "ON" position, when you want to adjust the length and switch to "OFF" position when you complete adjusting.)

210 mm

148.5 mm

Changing the Mop Head

Place the mop head on the ground, with the microfibre head facing downwards. Stand on the microfibre head near its centre to hold it in position whilst pulling the mop head away until it clicks. Replace the microfibre head by inserting it back into the mop head until it clicks and is fully secure.



CAUTION

Keep out of the reach of children.

Do not fill the water over the max water line.

Not suitable for use with bleach.

Do not expose to direct sunlight for prolonged periods of time.

Do not store near heat source.



dunelm.com
Manufactured in China for
Dunelm (Soft Furnishings) Ltd. LE7 1AD
& Dunelm (Soft Furnishings)
Londonderry Ltd. BT48 8QN

210 mm

148.5 mm