
PIZZA OVEN WITH PIZZA PEEL

INSTRUCTIONS





Dear Customer

Check the pack and make sure you have all the parts listed below. If not, contact the helpline on **03451 656565** who will be able to help you.

Safety advice

For outdoor use only.

For use with wood pellets. To start fire use cubes/blocks, lighting fluids or liquids, compliant with BS EN1860-3.

Locate the pizza oven outside in a well-ventilated area, away from any flammable structure and never on any combustable surface.

Place up to 0.5 kg of the wood pellets on to the fuel hopper.

The pizza oven must be placed on level ground prior to use.

Never leave a burning fire unattended.

Carefully unpack the pizza oven, The Pizza stone is fragile and can break if dropped.

Before first use, clean the pizza stone with warm water and dry thoroughly. Do not use washing -up liquid or any other cleaner/soap on the stone as these can be absorbed and impair the flavour of the pizza cooking on it.

Place the thoroughly dry pizza stone in the cold pizza oven before lighting. Never place a cold pizza stone in a hot oven, as it may damage it.

Pizza oven Safety

WARNING! This pizza oven will become very hot, do not move it during operation.

WARNING! Keep Children and pets at a safe distance from the product when in use.

WARNING! Do not use spirit or petrol for lighting or re-igniting.

Use only firelighters complying to BS EN1860-3.

Never attempt to pour lighting fluid or any flammable liquid on a pizza oven when it is lit.

ATTENTION! Do not leave the pizza oven unattending when it is lit or cooling down.

Ensure the pizza oven is completely cooled before attempting to remove the ash.


Do not use indoors.

Always use oven mitts or gloves for all handles or when adjusting the pizza oven.

Keep a fine water sprayer at hand to extinguish any small flare ups. Otherwise, use baking powder or salt to extinguish if the fire increases in size.

02

WARNING: CARBON MONOXIDE POISONING CAN KILL! NEVER USE ANY FUEL BURNING OVEN INDOORS OR INSIDE YOUR TENT OR AWNING.
THE FUEL CAN EMIT DANGEROUS CARBON MONOXIDE WHICH MAY RESULT IN DEATH. EVEN WARM OVEN CAN BE LETHAL.




WARNING! Do not use the pizza oven in a confined and/or habitable space e.g. houses, tents, caravans, motor homes, boats. Danger of carbon monoxide poisoning fatality. The pizza oven has to be installed on a secure level base prior to use.

03

Caution! Toppings may be extremely hot!


Parts and fittings Components




04

Assembly Instructions

1 Open the support legs (B) and stand up.




2 Install the small chimney (A) upright as shown in the picture.




Assembly Instructions

3 Install handle (D) to hopper (F) with screws (AA). Put partition (G) into fuel hopper. Then put the fuel hopper into pizza oven.





4 Install food door (C), handle (D)with screws (AA). Put the pizza stone into the pizza oven and close it with food door.




06

COOKING TIPS







5 Using pizza peel place the pizza onto the pre-heated pizza stone in oven and close the door. If using a fresh/soft base dust the pizza peel with flour or cornmeal to prevent sticking.

6 Rotate the pizza a third of the way in 30 second intervals to ensure evenly baked. Only leave the food door open for a minimum amount of time while loading or rotating pizza, to avoid excess temperature loss. Cooking time approx. 2 mins (based on a par-baked base, fresh/soft or frozen base times may vary). Ensure the product is thoroughly cooked before consumption.

CLEANING & CARE:

After cooking allow the fire to die down, while keeping the door closed. It may take 2.5hours to fully self extinguish.

Clean the pizza oven after each use.

Allow the pizza oven to cool completely before cleaning it.

Ensure that the fuel has completely cooled down before attempting to remove and empty the ash.

Do not use strong or abrasive solvents or scouring pads,

as these will damage the surfaces and leave marks.

Never pour cold water directly over the fuel after burning to extinguish, this can damage the product.

Empty the cold ashes and clean the product regularly, preferably after every use.

Remove loose deposits on the product with a wet sponge.

Generally, clean the inside and surfaces with warm water.

Dry with a soft, clean cloth. Do not scratch the surfaces when drying off.

Do not use washing-up liquid or any other cleaner/soap on the stone as these can be absorbed and impair the flavour of the pizza cooking on it, If required use only a solution of baking soda and warm water to aid cleaning. Never leave the pizza stone soaking in water, as absorbed water will impair its performance and could damage it.

80

Hand wash only, not suitable for dishwasher.

Storage:

Ensure the appliance is cool and clean before storing.

Store it in a dry place.

For longer-term storage and over the winter cover the pizza oven.