








Assembly Instructions

Ref	Description	Picture	Qty
A	Table Leg		4
B	Table Frame Ring		1
C	Table Top		1

Ref	Description	Picture	Qty
D	Tray		1
E	Head Bolt (M6*12)		12
F	Head Bolt (M6*20)		8

Ref	Description	Picture	Qty
G	Hex Wrench (4MM)		1
H			
I			


Code	Top	Leg	Table	Name	Name
30901720	SC/382	SC/534	FC/982	RIVERSIDE	RICHMOND
30901721	SC/387	SC/534	FM/987	MEMPHIS	MONTILLA
30901711	SC/389	SC/534	FM/989	GLENDALE	GRANADA
30901712	SC/392	SC/534	FM/992	VIRGINIA	VILLENA

PLEASE ASSEMBLE ON A SOFT SURFACE TO AVOID DAMAGING TABLETOP

Step 1: Assemble ring to legs. Step 2: Attach leg assembly to tray. Step 3: Bolt frame to tabletop, tighten all bolts once whole table is assembled.

PROTECT TABLETOP FROM FROST, for full care instructions visit
www.europaleisure.co.uk

In the event of difficulty, please call Consumer Services on 01722 742763



Europa Leisure



Code	Chair	Name	alt Name
	FR/192	WESTFIELD LOUNGE CHAIR	WINDSOR Lounge Chair

PLEASE ASSEMBLE ON A SOFT SURFACE TO AVOID DAMAGING TABLETOP







Step 1: Assemble ring to legs. Step 2: Attach leg assembly to tray. Step 3: Bolt frame to tabletop, tighten all bolts once whole table is assembled.

**PROTECT TABLETOP FROM FROST, for full care instructions visit
www.europaleisure.co.uk**



In the event of difficulty, please call Consumer Services on 01722 742763

Europa Leisure

Assembly instructions

Ref	Description	Picture	Qty	Ref	Description	Picture	Qty
A	Chair Leg (R&L)		2	D	HeadBolt (M6*14)		4
B	Chair Seat		1	E	HeadBolt (M6*30)		4
C	Chair Back		1	F	Hex Wrench (4MM)		1

Don't over tighten bolts during assembly



Tighten all bolts before use