









# **RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCES.** **ASSEMBLY TO BE CARRIED OUT BY A COMPETENT ADULT ONLY.**

Full assembly instructions including a part list and tools required.

## **PART LIST (for each unit)**

1	2	3	4	5	A	B	C
							
x2	x5	x5	x1	x1	x4	x10	x1

## **TOOLS REQUIRED**




Allen Key (Supplied)


Please follow the instructions below to assemble or disassemble the product.

## **HOW TO ASSEMBLE EACH UNIT**


- 1** Connect the short rods (#2) and (#3) to form 5 long rods.




- 2** Align the holes, use screw (#B) and wrench (#C) to secure the 5 long rods and side frame (#1) together.




- 3** Open the fabric cover (#4) and place the entire frame inside.



- 4** Insert the bottom cardboard (#5).






- 5** Close the fabric cover, flatten it, and zip it up.



**6 | The roller (#A) has two usage options. Easily choose the option that best suits your needs.**




**OPTION 1**

Press the roller (#A) into the corresponding slot.



**OPTION 2**

Press the roller (#A) into the corresponding slot.





**HOW TO DISASSEMBLE EACH UNIT**

Please use Allen Key (#C) and follow the instructions below.



**1**

Fit the Allen Key (#C) in to the gap.



**2**

Lever Allen Key (#C) until roller (#A) pops out.



## CARE AND MAINTENANCE INSTRUCTIONS

- **DO NOT** store or leave outside.
- Periodically check the tightening of fixings and screws.

## SAFETY TESTED

The product conforms to:  
**FIRA FRQG C001:2021 / FIRA FRQG C004:2016+A1:2017**

## WARNINGS

1. **WARNING: DO NOT** use this product if any part is broken, torn or missing. Please contact your supplier and spare parts can be supplied – please use only parts approved by the manufacturer.
2. Please keep children away from the work area during assembly of this product – due to small parts.
3. Dispose of all packaging carefully and responsibly.
4. We advise you to keep these instructions in a safe place in case required for future use.
5. Assembly to be carried out by a competent adult only.
6. This product is suitable for children in the age range 3+ years.
7. The maximum loading weight of each unit 15KG.
8. Storage capacity of each unit 37L.