

Instruction

Babymore
more for your baby

Air Motion Glide Crib



TBB V2/24

Babymore

Tel: +44 203 475 5588

Email: customerservices@babymore.co.uk

www.babymore.co.uk

IMPORTANT: READ CAREFULLY AND RETAIN FOR FUTURE REFERENCE

Your Babymore Air Motion Crib is intended for infant, from birth until 6 months, 9 kgs, or until they are able to sit unaided or pull or push themselves up on their hands and knees.

This crib is tested and approved to BS EN1130: 2019 Cribs and BS EN 16890:2017+A1:2021 Mattresses for cribs.

The crib must be placed on a horizontal floor .

Children shall not be allowed to play unsupervised in the vicinity of the crib.

The crib should be locked in the fixed position when the child is left unattended.

Always ensure "Feet to Foot" position, with or without use of wedge pillow.

Ensure everyone use your crib knows how to use it.

WARNING

- Do not use this product without reading the instructions for use first.
- Stop using the product as soon as the child can sit or kneel or pull itself up.
- Placing additional items in the product may cause suffocation.
- Be aware of the risk of open fires and other sources of heat, such as electric bar fires, gas fires, etc. in the near vicinity of the crib.
- Do not use crib if any parts are missing, damaged, or broken. Contact Babymore for replacement parts and instructional literature if needed. Do not substitute parts.
- Do not place the product close to another product, which could present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.
- Only use the mattress sold with this crib, L 82.5 x W 41 cm, maximum thickness of 3.5cm, do not add a second mattress on this one, suffocation hazards.
- Do not use more than one mattress in the product.
- All assembly fittings should always be tightened properly and that care should be taken that no screws are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies's dummies, etc), which would pose a risk of strangulation.

Crib Parts List



Bassinet



Wedge Pillow



Travel Bag



Leg x 4



Mattress

Assemble your crib

1 Unfold bassinet




2 Bassinet locked

CLICK x2



3 Press to insert



4 Insert 4 legs

CLICK x4



Assemble your crib (continue)

5

Studs x 4



6

Velcro x 2



7

Insert Mattress



8

Crib Ready



Glide your crib

1 Push to unlock



2 Gently push to glide



Lock Fixed Position

1 Pull to lock



2 Fixed position



"Feet to Foot" Position



Fold your crib

1 Remove mattress



2 Release two sides




Fold your crib (continue)

3 Bassinet unlocked



4 Remove legs



5 Put into bag



Care & Maintenance

The crib meets comprehensive safety standards, correct use and regular maintenance is essential and keeps necessary parts running effectively.

Storage - Always store your crib dry. To prevent mildew forming, always wipe away any moisture with a soft cloth and allow to dry before storing.

Cleaning - Refer to fabric wash care labels, plastic and metal parts may be sponged clean with warm water and a mild detergent. Never clean with abrasive types of cleaner.

Wear & Tear - Regularly check for loose fittings, worn parts, torn materials or stitching. Adjust or replace where necessary.

Maintenance - Regularly inspect the locking devices and fixtures to ensure they are secure and in full working order. A light application of a spray lubricant e.g. silicone (do not use oil or grease) will help free movement at all times.

Do not force it, if becomes difficult to adjust, fold or unfold. If difficulties persist, contact your supplier.

Warranty

Our 6 months warranty covers all manufacturing defects in materials and workmanship when used in normal conditions and in accordance with our user manual.

Available to first end-user customer of mainland UK, start from the date of original retail purchase, the warranty does not cover:

Damage caused by accidents, abusive use, negligence, fire, liquid contact or other external cause, damage which is the consequence of failing to comply with the user manual.

Damage caused by use with another product, service by anyone who is not authorised by us, or if any label or serial number has been removed from the product or changed.

Normal wear and tear, for example, worn down, natural breakdown of colours and materials normal aging. Damage caused by incorrectly stored, or failure to follow the instruction and guide.

If a problem should arise which you feel is covered by our warranty, please contact Babymore or an authorised retailer from whom you purchased your item. Proof of purchase and the product detail are necessary. This limited warranty does not affect your statutory rights.



Babymore

T: +44 203 475 5588

E: customerservices@babymore.co.uk

Serial No: xxx-xxx-xxx

Babymore

more for your baby

A i r
M o t i o n



#babymoreuk

Babymore Tel + 44 (0) 20 3475 5588 • www.babymore.co.uk

Unit C2 Zenith Ind Est, Paycocke Rd, Basildon, UK, SS14 3DW