



Assembly Instructions:

4. Before sitting on the chair, ensure that the front legrest is in the most upright position so that it is almost touching the ground Fig.5




5. To recline the chair: hold the front of the Armrests in each hand and slowly lean backward to the required position. Lock the chair in position by turning the locking knobs in the direction indicated. See Fig. 6 & 7. Ensure that when reclining the chair care is taken to avoid trapping fingers in any moving parts.



6. Please reverse the steps above to fold chair after use.

HELSINKI GRAVITY CHAIR INSTRUCTIONS



GARDEN FURNITURE CARE GUIDE

General Care Advice:

We recommend that you use a breathable cover for garden furniture when not in use and during the winter it should ideally be stored inside in a cool place with an airflow.

During bad weather and winter months the products should be stored in a dry place to avoid rusting.

Parasols should be left open to dry if they get wet and should always be taken down and put away in windy weather.

If you are placing furniture against a wall, leave a gap of at least 25mm to increase air flow around the product.

Always lift your furniture into place, avoid dragging it across the floor as this can cause damage to joints.

Avoid rocking backwards on two legs of chairs as this will weaken the joints.

Do not use a pressure washer or jet wash on any of your garden furniture.

Periodically, check the tightness of fixings and tighten if necessary.

Outdoor Cushions Care Advice:

All reversible cushions should be turned daily, and their positions switched, this will help prevent excessive soiling and ensure wear-out is even.

It is essential that all fibre cushions are given a vigorous plumping by shaking and squeezing to redistribute the fibre on a daily basis. This will add air into the fibres to ensure that they perform to the best of their ability and prevent the fibre going flat and lumpy.

Where possible, keep upholstery out of direct sunlight to avoid discolouring and fibre

This product is not suitable for use indoors

weakening. Garden furniture covers will fade slightly over time if left out in the sun for prolonged periods.

Avoid sharp items such as toys, jean rivets and buckles coming into contact with the upholstery as these can easily snag, tear or pull the fabric.

When not in use, we recommend you store furniture cushions indoors, rather than leaving them outside, as this will prolong their life.

Do not leave cushions out in the rain, if these do become wet, please be aware that the fillings inside may take longer to dry out.

For Accidental Spills or Stains:

Don't rub or scrub with a cloth as this could damage the fabric and remove the colour. Blot or soak up spills instead.

Don't use washing up liquid, detergents or bleach to remove stains from fabric.

Don't soak or allow fabric to become wet, be aware that the filling of the cushion will take longer to dry that the fabric.

Do not machine wash fabric cushion covers.

Metal Outdoor Furniture Care Advice:

Use a clean, dry cloth to dust the surface.

If there are stubborn marks use soapy water and a clean cloth, ensure that the water does not touch any other parts of the product. Afterwards use clean, dry cloth to remove any smears.

Do not use abrasive cleaners or cloths as these can scratch the surface of the metal.


Do not use chemical cleaners or polishes on any metal.

Ensure that mats are placed to prevent hot items coming into contact with the surface.


Do not put the chairs upside down on a glass table when not in use or on rainy day. If your furniture becomes stained, scratched, chipped or suffers other damage, we recommend professional help is sought to restore it. Please contact our customer services line for recommended agents.

Assembly Instructions:


1. After removing this item from its packaging, place the back leg of the chair on the ground and hold as shown in Fig.1



2. Unfold the chair - Holding the chair by the backrest tube in one hand, exert outward and downward pressure on the armrest with your other hand, this will cause the chair to open as indicated in Fig.2 & 3. Be careful not to trap or pinch your finger in the moving parts of the chair.



3. Placing one foot on the rear leg, slide the backrest back fully and then forward into the most upright position - Fig 4. Ensure that the front and back legs are in the fully extended position by checking that the back leg hinge and bracket are in the correct position as shown in Fig. 4a & 4b below. The chair must not be used unless these parts are in the correct position.



4a



4b