

## **Fitting Instructions for Apex Canopy with Composite Roof**

- 1 Mark a vertical line, using a level, 520mm from the centre of your door
- 2 Hold a gallows bracket against the wall, at the required height, (normally just above the top of the door frame) so that the inner edge is on the line drawn.
- 3 Mark the bottom gallows bracket hole position
- 4 Remove bracket and drill hole 10mm diameter 50mm deep
- 5 Hold bracket back in place and knock plug and screw through bracket in to drilled hole, partially tighten
- 6 Using spirit level ensure bracket is vertical and mark top hole
- 7 Move bracket to one side and drill top hole 10mm dia x 80mm deep
- 8 Reposition bracket and knock plug and screw into place and tighten both screws
- 9 Mark a vertical line on the wall on the other side of the door 1040mm from the inner edge of the fixed bracket
- 10 Using a spirit level position the second bracket ensuring it is vertically straight and level with the first bracket
- 11 Mark, drill and position second bracket as per instructions 3, 4 & 5
- 12 Place the 2 halves of the canopy together on the floor ensuring the line up correctly and insert the 3 screws to hold the top edge of the canopy together
- 13 Stick in place the top roof panel and ridge profile
- 14 Carefully using 2 people lift the canopy on to the 2 fixed brackets to check every thing is lined up correctly
- 15 insert 2 screws through front edge of gallows bracket into the front canopy profile
- 16 Drill 2 holes through back face of canopy into the wall 10mm diameter 110mm deep (80mm deep in wall), in an appropriate position to avoid mortar lines
- 17 Insert 2 screws through canopy into wall
- 18 Add finial to front top joint of canopy with a screw from inside the canopy
- 19 Insert truss into front of canopy and fix in place

